



## S450 Error Codes

**The POWER Light Flashes Orange when an error occurs. The number of consecutive orange flashes, in between the green flashes, indicates the cause of the problem.**

Two Flashes	Out of paper, paper jam, paper feed error
Three Flashes	Paper Jam
Four Flashes	BJ cartridge out of ink
Five Flashes	BJ cartridge not installed correctly
Six Flashes	BJ cartridge not installed/printhead worn out
Seven Flashes	BJ cartridge defective
Eight Flashes	Waste ink absorber almost full

---

**The power light flashes orange and green alternately: Service error**